

Trace analysis of environmental matrices by large-volume injection and liquid chromatography–mass spectrometry

Francesco Busetti · Will J. Backe · Nina Bendixen ·
Urs Maier · Benjamin Place · Walter Giger ·
Jennifer A. Field

Received: 28 May 2011 / Revised: 23 July 2011 / Accepted: 26 July 2011 / Published online: 17 August 2011
© Springer-Verlag 2011

Abstract The time-honored convention of concentrating aqueous samples by solid-phase extraction (SPE) is being challenged by the increasingly widespread use of large-volume injection (LVI) liquid chromatography–mass spectrometry (LC–MS) for the determination of traces of polar organic contaminants in environmental samples. Although different LVI approaches have been proposed over the last 40 years, the simplest and most popular way of performing LVI is known as single-column LVI (SC-LVI), in which a large-volume of an aqueous sample is directly injected into an analytical column. For the purposes of this critical review, LVI is defined as an injected sample volume that is $\geq 10\%$ of

the void volume of the analytical column. Compared with other techniques, SC-LVI is easier to set up, because it requires only small hardware modifications to existing autosamplers and, thus, it will be the main focus of this review. Although not new, SC-LVI is gaining acceptance and the approach is emerging as a technique that will render SPE nearly obsolete for many environmental applications. In this review, we discuss: the history and development of various forms of LVI; the critical factors that must be considered when creating and optimizing SC-LVI methods; and typical applications that demonstrate the range of environmental matrices to which LVI is applicable, for example drinking water, groundwater, and surface water including seawater and wastewater. Furthermore, we indicate direction and areas that must be addressed to fully delineate the limits of SC-LVI.

Published in the *10th Anniversary Issue*.

F. Busetti
Curtin Water Quality Research Centre, Department of Chemistry,
Curtin University,
Perth, Western Australia 6102, Australia

W. J. Backe · B. Place
Department of Chemistry, Oregon State University,
Corvallis, Oregon 97331, USA

N. Bendixen · U. Maier
Bachema Analytical Laboratories,
8952 Schlieren, Switzerland

W. Giger
GRC, Giger Research Consulting,
8049 Zurich, Switzerland

J. A. Field (✉)
Department of Environmental and Molecular Toxicology,
Oregon State University,
Corvallis, Oregon 97331, USA
e-mail: Jennifer.Field@oregonstate.edu

Keywords Large-volume injection · Direct injection ·
Liquid chromatography · LC–MS–MS · Soil · Solid-phase
extraction · Sample preparation · Water · Wastewater

Abbreviations

CC-LVI	Coupled-column large-volume injection
LVI	Large-volume injection
LOD	Limit of detection
LOQ	Limit of quantification
LC–MS–MS	Liquid chromatography–tandem mass spectrometry
MS	Mass spectrometry
ON-E	On-line enrichment
SC-LVI	Single-column large-volume injection
SPE	Solid-phase extraction
UV–Vis	Ultraviolet–visible absorption

Introduction

It is a widely held belief among chemists, instrument manufacturers, and companies that produce solid-phase extraction media that solid-phase extraction (SPE) is needed to extract analytes from aqueous samples, to reduce the complexity of the matrix and to increase analyte concentrations in the final extract. The authors of this critical review represent three generations of analytical environmental chemists, all of whom have performed SPE during their careers [1–5]. We, also, have held the belief that SPE is a “necessary evil” that protects our analytical columns and sensitive mass spectrometers. In one way or another, in some cases by serendipity, we have reached the conclusion that for many applications, large-volume injection (LVI) is chemically redundant with SPE. As a result, we postulate that LVI will render SPE obsolete as a sample-preparation step, especially for aqueous environmental samples.

Analytical chemists, by their very nature, tend to be cautious, especially when protecting their valuable instrumentation. The desire to protect analytical columns and mass spectrometers has created, in our view, a “folklore” that sample pre-treatment by SPE is needed to keep analytical columns and mass spectrometers clean and fully operational. Current opinion indicates that if SPE were eliminated one would experience shorter column lifetimes and the need for more frequent instrument cleaning and maintenance. In addition, SPE is thought to reduce matrix effects and many argue that SPE is required to avoid negative effects on sensitivity. Such perceived advantages are the rationale for including SPE, which has many costs, both time and financial, to laboratories. The costs start from purchasing the SPE media that typically are used once and discarded. In addition, there are costs associated with solvent usage and disposal. However, one of the largest costs is for the labor required to perform SPE. The time required to add and optimize a SPE pre-concentration step is substantial. Additionally, if performed on a stand-alone SPE apparatus or by use of on-line SPE instruments, one also incurs equipment costs and additional labor costs to optimize, operate, and maintain SPE instrumentation. SPE is performed with sample volumes usually ranging from milliliters to liters and the costs associated with shipping samples of such volumes must also be taken into consideration.

Besides costs, the multi-step nature of SPE, which includes media preparation, sample application, wash steps, elution, evaporation, and reconstitution is laborious and results in variable accuracy and precision. Artifacts from SPE media and support material are problematic for those analyzing for analytes associated with common laboratory materials such as PTFE (e.g., fluorochemicals) and hydro-

phobic analytes that are prone to losses (negative artifacts) [6]. As we will discuss, the physicochemical processes occurring during SPE and LVI are equivalent and, thus, no net advantage in terms of column and instrument performance or reduction in matrix effects are realized by performing SPE. LVI can appear to have pitfalls when it is performed without a thorough understanding of how it works and which factors must be controlled. Methods are developed faster without SPE and have similar or even improved accuracy and precision because of the simple nature of the process with the least amount of materials and handling involved. In the end, SPE uses time and resources that could be allocated elsewhere, and it does not have the advantages perceived by so many researchers in academia and in the analytical industry. The objectives of this critical review are:

1. to describe the history and development of LVI;
2. to discuss the factors that must be considered when creating and optimizing LVI methods;
3. to provide examples of applications for environmental matrices including surface, ground, drinking, and waste water, and for vegetables and soil;
4. to answer a set of “frequently asked questions” typically encountered from audiences; and
5. to propose future directions and areas that must be addressed for full exploration of the limits of LVI and how environmental analytical chemistry can be drastically improved by LVI.

With this critical review we challenge analytical chemists to think outside “classical chromatography” and to put their instruments to full use without the labor and costs of SPE.

The history of large-volume or direct-injection

In the late 1970s, Little and Fallick [7] reported what they called “new ways” of using refractometers and ultraviolet–visible (UV–Vis) detectors coupled to modular LC systems consisting of pumps and hand-operated injectors for analysis of trace organic pollutants (Table 1). For the first time, chemists were using LC systems as enriching devices to concentrate trace organics in place of other pre-extraction/concentration/clean-up procedures that existed at that time (e.g., liquid–liquid extraction). The “on-line enrichment” (ON-E) technique consisted of pumping a sufficient quantity of a filtered aqueous sample (200 mL) through a C_{18} column using an off-line or standalone pump. A solvent of greater elutropic strength was delivered by a second pump to elute the analytes for UV–Vis detection. The authors also pointed out that when concentrations were sufficiently high “only 0.5 to perhaps 2 mL of sample and pumping that across the column is sufficient to concentrate

Table 1 On-line enrichment (ON-E), coupled-column (CC-LVI) and single-column (SC-LVI) applications for environmental matrices based on UV-Vis detection and early MS detectors. Entries are grouped by date of publication and then by analyte class and cover the years 1975 to 1999

Chemical class	Sample matrix	Injection technique	Volume injected (μL)	Column void volume (μL)	Percentage of column void volume injected ^a	Detection	LOD	Ref.
Polycyclic aromatic hydrocarbons	River water	ON-E	200,000	2,400	8,333	UV-Vis	NA	[7]
Surfactants	Waste water	SC-LVI	250	605	41	UV-Vis	NA	[8]
Pesticides	Surface water	SC-LVI	5,000	1,587–2,645	189–315	UV-Vis	40–500 ng L^{-1}	[9]
	Ground water	CC-LVI	200	1,058	19	UV-Vis	1,000 ng L^{-1}	[10]
	Surface water	CC-LVI	770	529–1,058	73–146	UV-Vis	1,000 ng L^{-1} –100 ng L^{-1}	[11]
	Surface water	CC-LVI	2,000	1,058	189	UV-Vis	100 ng L^{-1}	[12]
	Surface, ground, drinking water	CC-LVI	4,000	529–1,058	378–756	UV-Vis	100 ng L^{-1}	[13]
	Surface, drinking water	CC-LVI	6,000	1,587	378	UV-Vis	100 ng L^{-1}	[14]
	Surface water	CC-LVI	2,000	1,058	189	UV-Vis	100 ng L^{-1}	[15]
	Surface, drinking water	CC-LVI	2,000	317–1,058	189–630	UV-Vis	100 ng L^{-1}	[16]
	Surface, drinking water	CC-LVI	2000	1,000	200	UV-Vis	500 ng L^{-1}	[17]
	Drinking water	SC-LVI	50	7.8	640	MS	<20 ng L^{-1}	[19]
Pharmaceuticals	Drinking water	SC-LVI	50	7.8	640	MS	<20 ng L^{-1}	[18]

NA, not available

^a Applications are reported only if the percentage of column void volume injected was $\geq 10\%$. The percentage of column void volume injected was calculated as $(5 \times 10^{-4} \times \text{column length (mm)} \times \text{column ID (mm)})^2 \times 1000$ [70]

enough organics for detection” [7]. To the best of our knowledge, this is one of the first publications demonstrating the possibility of analyzing samples by LC-UV-Vis without the need for a pre-concentration and/or a clean-up step. Since the early 1970s, several scientists started to look deeply into this attractive option and consequently were able to produce a number of reports on LVI methods for analysis of a variety of chemicals in different matrices.

The second approach developed in the late 1970s and early 1980s was use of a single analytical column (SC-LVI), which consisted of simply injecting a large volume of sample into an analytical column. Two early examples include Gloor and Johnson [8], who described the direct injection of 250 μL wastewater for determination of linear alkylbenzene sulfonates (LAS) by ion-pair LC with UV-Vis detection (Table 1). Kiso et al. [9] reported a method employing 5-mL samples for analysis of 15 pesticides listed in the Japanese guidelines for potable water down to 40–500 ng L^{-1} levels (Table 1). Up to this point, UV-Vis was the detector of choice, because routine quantitative detection by mass spectrometry had not yet been developed.

In the 1980s throughout the 1990s, pesticides and other organic contaminants were a major environmental concern. The urgency of developing fast and reliable analytical methods able to match environmental regulation with or without minimal sample preparation soon became clear. In the early 1990s, Hogendoorn and co-authors published a

series of papers [10–14] dealing with the analysis of a variety of pesticide residues in a range of environmental samples using a coupled-column large-volume injection (CC-LVI) technique. The column-switching and on-line clean up approach they developed consisted of:

1. pre-separation of the sample on a low-efficiency column;
2. diverting the analyte-containing fraction into a second column; and
3. final analysis of the sample fraction containing the analyte by LC-UV-Vis.

For example, Hogendoorn et al. determined methyl isothiocyanate at 1,000 ng L^{-1} levels by injecting 770 μL aqueous sample on to a low efficiency column and then diverting the analyte-containing fraction into a second analytical column followed by UV-Vis detection [11]. The elutropic strength of water enabled injection of large sample volumes into the column and the analyte’s capacity factors (k') affected the optimum injection volume. By correctly timing the divert valve that was positioned between the low-efficiency column and the analytical column, only the analyte-containing fraction was sent to the analytical column. Other examples of CC-LVI include the injection of 2 [15–17] to 4 mL [13] groundwater, drinking water, and surface water containing pesticides, and limits of detection in the range <20–1,000 ng L^{-1} (Table 1).

Between the 1990s and the 2000s, LCs coupled to mass spectrometers emerged but the capacity of the vacuum systems permitted only low mobile phase flow rates. Low LC flow rates ($\mu\text{L min}^{-1}$ rather than mL min^{-1}) required reduced LC column diameters (0.25–0.5 mm I.D. rather than 2.1–4.6 mm I.D.) and low injection volumes (nL rather than mL) [18]. Therefore, with the emergence of the first LC–MS systems, the development and application of LVI methods took a step backward. Limits of detection were confined by the restricted injection volumes that were compatible with the narrow-bore columns used at that time [18, 19]. With the advent of commercial mass spectrometers fitted with multiple-stage vacuum systems and with more efficient atmospheric pressure ionization (API) sources, higher LC flow rates, larger column diameters, and larger injection volumes were made possible. An increasing number of publications have since appeared in the scientific literature that describe SC-LVI for use with mass spectrometry for determination of pesticides in vegetables [20], water [21–29], and soil [30–33]; fluorochemicals in wastewater, groundwater, and surface water [33–37]; neurotoxins in surface water, groundwater, and drinking water [38, 39]; pharmaceuticals (legal and/or illicit) in surface, ground, and waste water [25, 33, 40–44]; corrosion inhibitors in surface, ground, and waste water [33, 45]; chelating agents in surface, drinking, and waste water [46]; iodinated chemicals in waste water and treated water [47–49]; artificial sweeteners in ground, waste, and treated water [50]; biocides in surface and waste water [51]; bisphenol A in soil [33]; steroids in waste water [52]; and surfactants in seawater (unpublished) (Table 2). The success and popularity of SC-LVI compared with ON-E and CC-LVI are most likely because of its simplicity.

SC-LVI: factors to consider when creating and optimizing methods

The aim of this section is to introduce readers to SC-LVI. For the purpose of this review, our working definition of SC-LVI includes those applications involving direct introduction of sample volumes that are $\geq 10\%$ of the void volume of the analytical column used for separations (Table 2). While reporting the percentage of the void volume injected is convenient for comparing disparate LVI applications, the percentage of the void volume injected cannot be used to predict analyte retention or capacity on a given column, because additional factors are important, for example particle size, column composition, and sample solvent matrix. SC-LVI differs from ON-E and CC-LVI because SC-LVI is performed without the use of off-line or on-line sample pre-concentration steps or equipment and does not require additional pumps, sorbents, or analytical columns. In this section, the factors involved in creating

and optimizing SC-LVI methods are covered. The order and function of each step involved in SC-LVI are discussed relative to the analogous steps used in treating the sorbent in SPE (Table 3).

Enrichment and analytical column conditioning step

The first step in SPE is to condition or “wet” the SPE media using microliters to milliliters of non-aqueous solvents to ensure reproducible retention and sample flow [53] (Table 3). The organic solvent also serves to reduce or eliminate sorbent impurities. The analogous situation in SC-LVI occurs only when a new enrichment/separation column is first installed and must be conditioned. Once the columns are conditioned and properly stored after use, no subsequent “wetting” steps are needed, because the column is not allowed to dry and normal operation of the LC re-equilibrates the enrichment/separation column.

Sample loading

The objective is to concentrate analytes on both SPE media and reverse-phase analytical columns during SC-LVI from aqueous samples or samples composed of a solvent–water mixture. Although most of the applications listed in Table 2 involve the direct injection of aqueous samples, several indicate that extracts of vegetables [20] or soil [30–32] are analyzed by SC-LVI (Table 2). The final organic solvent-based extracts were diluted with water and the injected samples analyzed by SC-LVI ranged in composition from 25% organic solvent (acetonitrile or methanol) and 75% water to up to 70% organic solvent and 30% water. These examples indicate that SC-LVI can be used with samples that are not 100% aqueous and that analytes can be focused on the analytical column in the presence of organic solvent. In SC-LVI, sample loading in which the sample is dissolved in the mobile phase is equivalent to isocratic separations with a very elutropically weak solvent (e.g., 100% aqueous). The injected sample volume and flow rate determine the duration of the isocratic loading conditions. For example, a 4.5-mL injection at 1 mL min^{-1} would be equivalent to an isocratic separation of approximately 4.5 min.

Sample volumes for SPE and SC-LVI are selected as a function of analyte concentration and detector sensitivity. For SPE applications, the sample volumes processed range from $<1 \text{ mL}$ to $1,000 \text{ mL}$, whereas volumes up to 5 mL are used in SC-LVI (Table 2). In both cases, sample volumes should not exceed the breakthrough volume of analytes [11, 53–56]. In SC-LVI, maximum injection volumes are determined by injection assemblies consisting of syringe plungers and sample loops. Syringe plungers and sample loops are matched by volume to ensure the sample

Table 2 SC-LVIMS applications for environmental matrices (organized by earliest date of publication for individual classes of analytes that then occur in alphabetical order when the first year of publication is equivalent) covering the time from 2000 to 2010

Chemical class	Matrix	Sample preparation	Maximum volume injected (μL)	Column void volume (μL)	Percentage of column void volume injected ^a	LOD (LOQ ^b)	Ref.
Pesticides	Vegetables	Solvent extraction, dilution with water	900	530	170	0.5–2 $\mu\text{g kg}^{-1}$	[20]
	Surface, ground, drinking water	Filtration	11,700	1,058	1,106	10–200 ng L^{-1}	[21]
	Drinking water	None	250–2,000	80–530	113–646	100 ng L^{-1}	[22]
	Surface, ground, drinking water	Filtration, acidification	1,000	1,590	63	10–20 ng L^{-1}	[23]
	Surface, ground, drinking water	Dilution	100	793	13	100 ng L^{-1}	[24]
	Surface, ground, drinking, waste water	Filtration	100	100	100	10–100 ng L^{-1}	[25]
	Surface, drinking water	Filtration	100	529	19	<15 ng L^{-1}	[26]
	Mineral water	Degassed	100	100	100	100–1,000 ng L^{-1}	[27]
	Drinking water	Centrifugation	100	330	30	<100 ng L^{-1}	[28]
	Surface, ground, drinking water	None	50	220	23	10 ng L^{-1}	[29]
Fluorochemicals	Soil	Solvent extraction, centrifugation, evaporation	20	10	296	300–500 $\mu\text{g kg}^{-1}$	[30]
	Soil	Solvent extraction, dilution with water	1,000	1,000	100	300 $\mu\text{g kg}^{-1}$	[31]
	Soil	Solvent extraction, dilution with water	1,000	1,000	100	7–18 $\mu\text{g kg}^{-1}$	[32]
	Soil	Solvent extraction, dilution with water	100	221	45	0.23–0.69 $\mu\text{g L}^{-1\text{b}}$	[33]
	Ground water	Centrifugation	900	300	300	150–1,800 ng L^{-1}	[34]
	Waste water	Centrifugation	500	300	167	0.5 $\text{ng L}^{-1\text{b}}$	[35]
	Surface, waste water	Centrifugation	900	331	272	1–300 ng L^{-1}	[36]
	Surface, waste water	Filtration	100	110	91	0.3–1.6 ng L^{-1}	[37]
	Surface, ground, drinking, waste water, sewer biofilm, soil	Water: none; soil: extraction, activated carbon	500	221	227	4–8 $\text{ng L}^{-1\text{b}}$	[33]
	Drinking water	Filtration	500	2,000	25	200 ng L^{-1}	[38]
Neurotoxins	Surface, ground, drinking water	Centrifugation	750	1,058	71	30 ng L^{-1}	[39]
	Surface, ground, drinking water	Filtration	25	0.8	3,125	50 ng L^{-1}	[40]
	Drinking, ground, surface, and waste waters	Filtration	100	100	100	10–100 ng L^{-1}	[25]
	Waste water	Centrifugation	1,800	1,587	113	2.5–10 ng L^{-1}	[41]
	Surface water	Filtration, dilution	3000	44	6,803	2–10 ng L^{-1}	[42]
	Surface water	Filtration	100	300	33	0.2–100 ng/L	[43]
	Waste water	Filtration	5,000	22	22,676	3–8,130 ng L^{-1}	[44]
	Waste water	filtration	500	221	227	9–18 $\text{ng L}^{-1\text{b}}$	[33]
	Surface, ground, drinking water	Filtration	60	300	20	33 ng L^{-1}	[45]
	Surface, ground, drinking, waste water	Filtration	500	221	227	32–7 $\text{ng L}^{-1\text{b}}$	[33]
Corrosion inhibitors	Surface, ground, drinking water	Filtration	50	300	17	(600–1,000) ng L^{-1}	[46]
	Drinking, surface, and waste waters	Filtration	50	300	17	(600–1,000) ng L^{-1}	[46]

Table 2 (continued)

Chemical class	Matrix	Sample preparation	Maximum volume injected (μL)	Column void volume (μL)	Percentage of column void volume injected ^a	LOD (LOQ ^b)	Ref.
Iodinated contrast media	Waste, post-membrane filtration and reverse osmosis water	Filtration	100	675	15	110–970 ng L ⁻¹	[47, 48]
Artificial sweeteners	Wastewater, post-reverse osmosis water	Filtration, dilution	100	675	15	<500 ng L ⁻¹	[49]
	Ground, waste, post-microfiltration reverse osmosis water	Filtration	100	330	30	0.7–2.4 $\mu\text{g L}^{-1}$	[50]
Biocide	Surface, waste, membrane flushing water	Filtration	2000	2910	69	30–100 ng L ⁻¹	[51]
Bisphenol A	Soil	Solvent extraction, dilution	100	22	227	610 ng L ⁻¹	[33]
Steroids	Surface, waste water	Centrifugation	1,800–4,500	1,587	113–284	1.2–360 ng L ⁻¹	[52]
Surfactants	Sea water	Centrifugation	1,800	331	272	NA	Place et al. in preparation

^a Applications are reported only if the percentage of column void volume injected was $\geq 10\%$. The percentage of column void volume injected was calculated as $(5 \times 10^{-4} \times \text{column length (mm)} \times \text{column ID (mm)})^2 \times 1000$ [70]

^b Limit of quantification

NA = not available

withdrawn by the syringe can be accommodated by the sample loop. For example, applications that consist of injecting 100 μL can be accomplished with a 100- μL analytical head and sample loop without hardware modification.

For sample volumes that exceed the analytical head capacity (e.g., 100 μL), it is necessary to make simple hardware modifications. For some commercial LCs, analytical heads can be exchanged for larger-volume models. For example, Schultz et al. [35] and Huset et al. [36] replaced 100- μL syringes with a 900- μL syringe and a 1,400- μL sample loop. They operated the LC in “multi-draw” mode, which enabled multiple injection giving a total volume that exceeded the syringe and sample-loop volumes. To achieve injection of 1,800 μL , two cycles of 900 μL injections are performed [41]. Backe et al. used a 5,000- μL sample loop and five cycles of 900 μL to achieve an injection volume of 4,500 μL for anabolic steroids in water [52].

Flow rates

The application of high pressure for SC-LVI maintains flow rates despite the small particle size and is more efficient than SPE. SPE systems typically have a smaller number of theoretical plates and, therefore, efficiency, owing to the relatively large particle size and short column length compared with analytical columns with smaller particle sizes and greater lengths. The normal operating flow rate range during the application of samples processed by SPE is narrow and typically 1–10 mL min^{-1} . This upper flow rate is dictated by the small pressure drop than can be maintained by vacuum over the typically short SPE column beds (e.g., 1 cm) and the larger particle sizes (e.g., 40 μm) of SPE media [53]. One can directly compare the time required to transfer a large-volume sample to the analytical column during SC-LVI with the time and equipment it takes to prepare an extract by SPE, which ranges from minutes to hours (Table 3). This shift in sample-preparation time to the LC and away from laboratory personnel results in cost saving because labor costs are much greater than those associated with running the LC for a few extra minutes.

Programmed flow rates can be used in SC-LVI to load large volumes of samples into the enrichment/separation column quickly in order to reduce analysis time [52]. For example, Backe et al. transferred sample from sample loops to the analytical column at 1 mL min^{-1} after which the flow rate was reduced to 0.5 mL min^{-1} to separate anabolic steroids in wastewater. It is important to note that if the analytes of interest do not have a sufficiently high capacity factor in the sample solvent, decrease in retention and resolution can occur when a higher flow rate is used to load the sample and a slower flow rate for separation.

Table 3 Comparison of steps in solid-phase extraction (SPE) and in single-column large-volume injection (SC-LVI)

Steps	SPE	SC-LVI
Conditioning	μL to mL organic solvent(s)	Performed by mobile phase
Sample volume; time	1–1,000 mL; minutes to hours	Up to 5 mL; minutes
Washing	μL to mL of water and/or solvent	Performed by mobile phase
Drying	Often, but not always, included	NA
Elution	μL to mL of organic solvent	Performed by mobile phase
Extract concentration	Extracts typically concentrated under stream of N_2	NA
Extract injection	5–100 μL of final extract injected	NA

NA = not applicable

Dwell volume: chromatographic control and minimizing run times

When the analytical head/needle and sample loops have been loaded (chromatographic “time zero”), the total sample volume is then pushed on to the enrichment/separation column by the mobile phase flow. Note that it takes time to transfer the sample from the large-volume of injector tubing on to the column and this time must be taken into account when designing the gradient program. The initial gradient conditions, whether 100% aqueous or a solvent–water mixture, will not reach the analytical column until the total sample volume in the injector sample loops are transferred on to the enrichment/separation column.

Sample load time can be calculated by using the mobile phase flow rate, the volume of the capillary and tubing before the column, and the volume of the sample in the needle loop before the sample capillary. For example, at a flow rate of 0.5 mL min^{-1} , the column loading time for a $1,800 \mu\text{L}$ sample should be $(1,400 \mu\text{L} + 900 \mu\text{L total injection volume}) / 500 \mu\text{L min}^{-1}$ injection rate, = 4.6 min total injection time. Additional volume, as much as 3 x over the calculated volume, is usually needed to completely transfer the sample onto the column because of the parabolic flow of liquids in capillaries. This simple calculation may not fully account for the entire volume of the injection system, therefore further experiments are typically necessary to determine the exact loading time. A more empirical method for determining sample loading times is to map the pressure isotherm for samples whose viscosity is significantly different from that of the mobile phase. For example, water has a lower elutropic strength and higher viscosity than mobile phases containing methanol or acetonitrile. As aqueous samples are being loaded on to the column, fluctuations occur in pressure. After initiating an injection, the return in pressure to the initial starting pressure indicates that the aqueous sample has completely passed through the guard/analytical column. Another method of calculating sample loading times is to

monitor the presence of an unretained ($k'=0$) analyte, for example thiourea or acetone [41, 57]. The arrival time of an unretained peak takes into account the time it takes for the sample to pass from the column to the detector, which is negligible for a well designed system.

All of these methods are based on the assumption that the analytes in the sample are not interacting with (i.e., are not retained by) the materials in the injection assembly. If this is not the case, it may be necessary to run additional mobile phase through the injection assembly to quantitatively transfer all the analytes to the column after the sample loading phase [52]. Understanding the time it takes for large volumes (e.g., milliliters) of sample to be completely transferred into an analytical column is important when creating gradient programs and minimizing run times. In autosamplers, the system dwell volume, which is the volume the mobile phase occupies after the point of mixing to the head of the analytical column [58], can be quite large compared with normal systems, because of increased volume associated with sample loops (e.g., hundreds of microliters). Initial attempts to control SC-LVI for sample volumes of 900 and $1,800 \mu\text{L}$ were conducted without taking advantage of the mainpass/bypass valve that is present in the Agilent 1100 [41]. SC-LVI systems may seem to be unresponsive to changes in gradient settings unless the dwell time and volume of the injector are taken into account. Further, six-port injection valves positioned after the sample loops (e.g., seat capillary) and before the guard/analytical column, can be used to direct mobile phase flow around the injection assembly after the sample has been loaded into the column in order to significantly reduce dwell volumes and analysis times. In “mainpass mode”, the mobile phase is routed through the entire network of injector tubing and this mode is used to transfer sample on to the analytical column. “Bypass” mode is used after the sample has been transferred to the column and is achieved by rotating the valve so that mobile phase goes directly to the analytical column, thus bypassing the injector.

Washing SC-LVI columns

In SPE, the sorbent is often washed with a solvent or mixture of solvents of elutropic strength less than that required to elute the analytes of interest [56]. Wash steps are performed by incorporating a high percentage aqueous isocratic wash step, to eliminate salts, followed by a wash with a sufficient percentage of organic solvent, to elute all components from the SPE sorbent except the analytes of interest. In SC-LVI, wash steps are potentially important. It is our experience that successful SC-LVI must include a wash step. For example, without a wash step, Chiaia et al. observed relative standard deviations (RSDs) of $\geq 30\%$ for illicit drugs in wastewater [41]. A 1-min wash (at 0.5 mL min^{-1}) with a mixture of 90% (v/v) 0.1% acetic acid in 5% aqueous methanol and 10% (v/v) acetonitrile reduced RSDs to $< 12\%$. Analysts actually have more control over the wash step in SC-LVI than in SPE, because retention of the analytes is monitored simultaneously. In addition, matrix components that elute earlier and later than the analytes of interest are discarded to waste by use of a post-column divert valve, which will be discussed in more detail. Note that while wash steps can eliminate salts and their potential for causing matrix effects, wash steps cannot eliminate co-eluting matrix components during either SPE or SC-LVI.

Post-column divert valve

If a mass spectrometer is used as a detector for LVI analysis, the authors of this paper recommend addition of a post-column divert valve for mass spectrometers that do not come equipped with one. The purpose of the post-column valve is to divert early eluting matrix components, for example salts and highly polar organic interferences, away from the mass spectrometer to waste. This is especially important for mass spectrometers whose interface spray is not orthogonal or off axis to the capillary inlet. Diverting unwanted sample components protects the mass spectrometer from non-volatile sample components that might otherwise clog capillaries or eventually build up on optics. A divert-valve also reduces the amount of non-dissolved aerosol droplets sprayed directly or indirectly on to capillaries and orifices by diverting to waste the high aqueous fraction of the mobile phase gradient, which is more resistant to desolvation.

Eliminated and redundant steps in SPE

No steps analogous to the drying of SPE sorbent beds and extract concentration are needed in SC-LVI. The elution of SPE media is accomplished as part of SC-LVI whereas in SPE the sorbent media is eluted and then the analytes are eluted again from the analytical column, effectively repeat-

ing the same task twice when performing SPE followed by LC-MS analysis. In addition, typically only a small portion of the SPE extract generated is actually injected. Therefore, much of the time, materials, and labor required to generate the SPE extract is wasted. In contrast, SC-LVI is more cost and time-efficient because the entire sample is used.

In conventional SPE, a typical volume of water extracted by SPE is 100 mL. If 100% of a 50 ng L^{-1} solution were extracted and ended up in a 1-mL final extract, the concentration would be increased 100-fold. However, when only 10 μL is injected of the final extract, 0.05 ng is injected, which is only 1% of the original mass isolated by SPE. In contrast, if 1,800 μL the same 50 ng L^{-1} solution of analyte were directly injected, 0.09 ng is injected on to the column, which is greater than the amount introduced by the SPE approach.

Practical aspects of LVI

A good starting point would be to check the maximum allowable injection volume by the LC's syringe pump and sample loops (seat capillaries). Often, larger analytical heads and seat capillaries that enable multiple "draws" of a single sample can be purchased for use with existing systems. The concentration ranges of the analytes in the crude samples, the limits of detection required for the specific application, and MS sensitivity should be taken into account. One needs to consider the instrumental detection limits in terms of the total mass (e.g., picograms or nanograms) injected on to analytical columns, which are currently detected on the basis of injection of analytical standards into the system. This provides information on:

1. what volume to inject; and
2. whether an upgrade of the LC system with a multi-draw injection kit is needed.

For the starting configuration, it is important to estimate or measure the system's dwell time, which is the time it takes for a selected volume of sample to be transferred to the column.

Sample preparation for aqueous and solid samples

For aqueous samples, minimal sample preparation, for example centrifugation, is sufficient to prolong column life and avoid contamination from SPE or filtration materials. Samples to be injected by SC-LVI on to enrichment/separation columns must still be as particle-free as possible to avoid plugging the system. Filtration is commonly used [23, 25, 26, 37, 45, 47, 48]. Centrifugation is simple, requires no specialized training, uses widely available equipment, generates no solid waste, and samples can be treated in batches [35, 41, 52].

There are a limited number of cases in which SC-LVI is used for analysis of pesticides extracted from soil [31, 32, 33] and vegetables [20] by use of organic solvents such as methanol. In each of these cases, the methanol extracts are first diluted with water to give sample compositions ranging from 25:75 to 70:30 (methanol–water). The diluted extracts are then analyzed by injection of 100 to 1,000 μL (Table 2) with good retention and peak shape. The retention of analytes under SC-LVI conditions for organic solvent extracts diluted with water of varying elutropic strength is likely to be analyte-dependent.

LC columns and MS conditions

If an LC separation uses 100% aqueous phase at the beginning of the chromatographic run, then fully end-capped stationary phases should be used that are designed to not collapse at 100% aqueous phase during storage and that favor retention of highly polar compounds. Column diameters, LC flow rates, and mobile phase composition should be used that are compatible with the vaporization efficiency of the MS source. For example, most ESI sources can accommodate 100% aqueous phase at 200–300 $\mu\text{L min}^{-1}$ for 2.1–3.0 mm I.D. columns. Chiaia et al. increased the ESI source and desolvation temperatures to 150 and 450 $^{\circ}\text{C}$, respectively to accommodate the higher flow rates of 0.5 mL min^{-1} [41]. Alternatively, APCI can accommodate milliliter-per-minute 100% aqueous phase flow rates with 4.6 mm I.D. columns. Increasing the percentage of organic phase in the initial mobile phase will increase desolvation efficiency and reduce LC backpressure, so higher flow rates can be used. This could result in increased desolvation efficiency because of an increase in the desolvation path.

Speed and injection speed

Sample draw speed and injection speed will affect the time taken to load sample on to the enrichment/separation column. For aqueous samples, draw speed, and injection speed can be set to 900 $\mu\text{L min}^{-1}$ [52]. However, because of the viscosity of water, very high draw speed and injection speed are not recommended, because of the possibility of creating suction during sample withdrawal. To check this, initial injection tests should be performed at low draw/injection speeds (e.g. 100 $\mu\text{L min}^{-1}$) on vials containing known amounts (by mass or volume) of water. The volume effectively injected by the system can be assessed by difference in weight and/or volume. If this test does not reveal any problem, then the draw/injection speeds should be increased to 500 $\mu\text{L min}^{-1}$ or higher.

Operation of SC-LVI LC–MS methods under accredited conditions, and long-term performance

Several methods using SC-LVI LC–MS have been successfully operated in an analytical laboratory accredited according to ISO 17025 [33]. According to this contract laboratory, rigorous requirements regarding method validation including quality assurance and quality-control performance were met by the SC-LVI LC–MS approach. Column lifetimes were reported to be more than 300 days with 2,800 to 3,700 SC-LVI runs per column. In comparison with conventional LC–MS procedures, neither shorter column lifetimes nor a faster decrease of MS sensitivity were observed.

Effect of matrix effects on SC-LVI LC–MS analysis

Matrix effect components present in contaminated water samples are known to suppress and, less frequently, enhance the absolute response of the analyte [59]. This often results in variable detection limits and, more importantly, erroneous quantitative results. It should be borne in mind that matrix effects do exist in both SPE and SC-LVI LC–MS methods [45]. Therefore, the “tools” that are used to address matrix effects are the same for both approaches and include:

1. tunable LC gradients for on-line clean-up [35, 41, 52];
2. deuterated standards [43];
3. standard addition and matrix-matched calibration curves [25, 43, 47]; and
4. sample dilution [60].

Although matrix effects are compound and sample-dependent, they have been shown to be moderate to minimal for SC-LVI [25, 45, 47].

Instrumental background and LVI

Several reports indicate problems with instrumental background for fluorochemical analytes. This is partly because of components of LC systems, for example PTFE frits, seals, and tubing [35, 61–63] and partly because of plasticizers in solvents [64]. For the purposes of this discussion, “ghost” peaks are described as chromatographic peaks with retention times and MS transitions that correspond to the analyte of interest and increase overall detection limits. Such “ghost” peaks result from instrumental background contamination of the LC system and its parts [64] and are differentiated from peaks resulting from sample contamination (e.g., the presence of analytes within blank standards) or because of carryover from previously injected samples.

With the injection of large volumes, background contamination arising from LC system components can be

much more apparent than for smaller injection volumes, because of the longer sample loading phase with highly aqueous samples and resulting contact with LC system components that can lead to the buildup of hydrophobic analytes on the head of the analytical column. A “no injection run”, which simulates the entire injection sequence without actually introducing any sample, is a useful method for differentiating background contamination from contamination associated with samples [61]. If multiple no-injection runs give a constant ghost peak, this indicates background system contamination; decreasing peak areas indicate carry-over from previous sample injections.

In the development of a SC-LVI method for the surfactants present in the oil dispersant used on the Gulf of Mexico oil spill, a ghost peak for the dioctylsulfosuccinate (DOSS) surfactant was observed that had a retention time and MS transitions identical with those of the DOSS standard. For this method, 1,800 μL seawater were injected on to a C_{18} column (Table 2) and the divert valve was used to direct the highly saline sample matrix to waste instead of to the mass spectrometer. The ghost DOSS peak was identified as originating from the LC pump assembly. A second column was installed after the LC mixer but before the injector assembly, as described in Powley et al. [61]. The presence of this column shifted the ghost peak in time so that it was separated from the analyte peaks. In our experience, to affect separation of ghost and sample analyte peaks we have found that it is especially important that the column located between the LC pumps and the injector has retention equal to or greater than that of the analytical column. This finding indicates that LVI can be performed for applications in which background contamination is present.

UPLC with LVI

The main reason for using a UPLC rather than HPLC is the speed advantage. Ultra-performance liquid chromatography (uHPLC or UPLC) uses sub- $2\text{-}\mu\text{m}$ particles to achieve improved speed of analysis (5–10 times faster) and separation efficiency. A net advantage of UPLC over HPLC is also increased MS sensitivity. Because of the sub- $2\text{-}\mu\text{m}$ particles and the milliliter per minute flow rates typically adopted, the UPLC equipment must accommodate back pressures up to 1.03×10^8 Pa (15,000 psi). Smaller particles (e.g. $1.8\text{ }\mu\text{m}$ and below) are more prone to blockages, because the gaps between the particles are extremely small. For this reason, direct analysis of crude samples is a potential problem area for UPLC. To reduce column plugging and for longer columns lifetime, ultra in-line filters are now sold with UPLC columns and sample filtration through filter membranes is strongly recommended. However, this may be problematic for analytes that are

retained by filters or are artifacts of filter manufacture. As an alternative to UPLC, columns containing $2.5\text{-}\mu\text{m}$ fused-core particles can have efficiencies similar to those of the smaller $1.8\text{ }\mu\text{m}$ UPLC columns without requiring high back pressure, so they can be used in conventional HPLC systems [43]. Mass spectrometers coupled with UPLC systems must have high-speed acquisition for the narrow UPLC peaks. High-speed acquisition is also desirable to enable screening of wider lists of known and unknown analytes in a single chromatographic run without compromising sensitivity and sampling rate across chromatographic peaks.

Future perspectives

Despite the benefits of SC-LVI, there is apparent reluctance within the environmental analytical chemistry community to adopt this practice. Although SC-LVI applications date back to 1977 [8], the development of SC-LVI applications results from serendipity rather than from guidance based in theory. Research is needed to systematically define the limits of SC-LVI for complex environmental and biological matrices to make SC-LVI more generalizable, which is likely to lead to a fundamental understanding of the technology and its widespread application.

Existing literature describes peak shapes as a function of injection volume, analyte physicochemical properties, column dimensions, and sample composition under isocratic (loading and elution) conditions for clean water systems [65–68]. However, research is needed to determine whether relationships that are true for clean systems also apply to complex matrices (e.g., wastewater, urine, and blood). For example, research is needed to relate the capacity factors (k') of chemicals under isocratic loading conditions to the maximum amount of a sample that can be injected for a specific analyte while maintaining acceptable peak shape. This is important, because the capacity of an analyte under loading conditions is likely to be the limiting factor that determines the maximum injection volume for complex environmental samples, and, therefore, maximum attainable sensitivity. To date, research on maximum loading volume has focused on microbore columns and on how sample solvent composition and injection volume effect efficiency and area counts [68, 69]. As indicated earlier, LVI is compatible with injection of extracts obtained from environmental solids with appropriate dilution of extracts with water. However, this approach for analysis of organic solvent-containing extracts has yet to be fully exploited.

Matrix components from environmental samples may limit the volume of sample that can be directly injected on to the column. Matrix components may interact with analyte molecules in the column in a way that cannot be predicted by experiments on clean systems. Furthermore, matrix components may have the ability to displace

analytes and adversely affect peak shape, especially analytes that co-elute with large amounts of matrix components. Further, more detailed experiments, for example those using 2D chromatography, are needed to differentiate matrix effects because of column overloading from those associated with ionization. Direct comparisons of area counts for SPE extracts of environmental samples with those obtained by SC-LVI are needed to quantify any reduction or enhancement in matrix effects under SC-LVI conditions compared with SPE. Undoubtedly, increased mass spectrometer sensitivity can offset the need for large-volume injections, so direct injections of smaller volumes will provide equivalent or better sensitivity.

References

- Jonkers N, Sousa A, Galante-Oliveira S, Barroso CM, Kohler HPE, Giger W (2010) *Environ Sci Pollut Res* 17:834–843
- Alumbaugh RE, Gieg LM, Field JA (2004) *J Chromatogr A* 1042:89–97
- Busetti F, Heitz A, Cuomo M, Badoer S, Traverso P (2006) *J Chromatogr A* 1102:104–115
- Altenbach B, Giger W (1995) *Anal Chem* 67:2325–2333
- Field JA, Monohan K (1995) *Anal Chem* 67:3357–3362
- Martin JW, Kannan K, Berger U, de Voogt P, Field J, Franklin J, Giesy JP, Harner T, Muir DC, Scott B, Kaiser M, Jarnberg U, Jones KC, Mabury SA, Schroeder H, Simcik M, Sottani C, van Bavel B, Karrman A, Lindstrom G, van Leeuwen S (2004) *Environ Sci Technol* 38:248A–255A
- Little JN, Fallick GJ (1975) *J Chromatogr* 112:389–397
- Gloor R, Johnson EL (1977) *J Chromatogr Sci* 15:413–423
- Kiso Y, Li H, Shigetoh K, Kitao T, Jinno K (1996) *J Chromatogr A* 733:259–265
- Hogendoorn EA, Dejong A, Vanzoonen P, Brinkman UAT (1990) *J Chromatogr* 511:243–256
- Hogendoorn EA, Verschraagen C, Brinkman UAT, van Zoonen P (1992) *Anal Chim Acta* 268:205–215
- Hogendoorn EA, Vanzoonen P (1992) *Fresenius J Anal Chem* 343:73–74
- Hogendoorn EA, Brinkman UAT, van Zoonen P (1993) *J Chromatogr A* 644:307–314
- Hogendoorn EA, Hoogerbrugge R, Baumann RA, Meiring HD, de Jong A, van Zoonen P (1996) *J Chromatogr A* 754:49–60
- Hidalgo C, Sancho JV, Hernandez F (1997) *Anal Chim Acta* 338:223–229
- Sancho JV, Hidalgo C, Hernandez F (1997) *J Chromatogr A* 761:322–326
- Hernandez F, Hidalgo C, Sancho JV, Lopez FJ (1998) *Anal Chem* 70:3322–3328
- Rezaei MA, Famigliani G, Cappiello A (1996) *J Chromatogr A* 742:69–78
- Cappiello A, Famigliani G, Berloni A (1997) *J Chromatogr A* 768:215–222
- Hogenboom AC, Hofman MP, Kok SJ, Niessen WMA, Brinkman UAT (2000) *J Chromatogr A* 892:379–390
- van der Heeft E, Dijkman E, Baumann RA, Hogendoorn EA (2000) *J Chromatogr A* 879:39–50
- Dijkman E, Mooibroek D, Hoogerbrugge R, Hogendoorn E, Sancho JV, Pozo O, Hernandez F (2001) *J Chromatogr A* 926:113–125
- Ingelse BA, van Dam RCJ, Vreeken RJ, Mol HGJ, Steijger OM (2001) *J Chromatogr A* 918:67–78
- Huang SB, Mayer TJ, Yokley RA, Perez R (2006) *J Agric Food Chem* 54:713–719
- Seitz W, Schulz W, Weber WH (2006) *Rapid Commun Mass Spectrom* 20:2281–2285
- Diaz L, Llorca-Porcel J, Valor I (2008) *Anal Chim Acta* 624:90–96
- Greulich K, Alder L (2008) *Anal Bioanal Chem* 391:183–197
- Smith GA, Pepich BV, Munch DJ (2008) *J Chromatogr A* 1202:138–144
- Kowal S, Balsaa P, Werres F, Schmidt TC (2009) *Anal Bioanal Chem* 395:1787–1794
- Rosales-Conrado N, Leon-Gonzalez ME, Perez-Arribas LV, Polo-Diez LM (2002) *Anal Chim Acta* 470:147–154
- Chalanyova M, Paulechova M, Hutta M (2006) *J Sep Sci* 29:2149–2157
- Rybar I, Gora R, Hutta M (2007) *J Sep Sci* 30:3164–3173
- Bachema Analytical Laboratories Schlieren Switzerland (2011) <<http://www.bachema.ch/analyse-methoden/wasser/einzelanalysen/>> Accessed 21 July 2011
- Schultz MM, Barofsky DF, Field JA (2004) *Environ Sci Technol* 38:1828–1835
- Schultz MM, Barofsky DF, Field JA (2006) *Environ Sci Technol* 40:289–295
- Huset CA, Chiaia AC, Barofsky DF, Jonkers N, Kohler HPE, Ort C, Giger W, Field JA (2008) *Environ Sci Technol* 42:6369–6377
- Furdui VI, Crozier PW, Reiner EJ, Mabury SA (2008) *Chemosphere* 73:S24–S30
- Cavalli S, Polesello S, Saccani G (2004) *J Chromatogr A* 1039:155–159
- Marin JM, Pozo OJ, Sancho JV, Pitarch E, Lopez FJ, Hernandez F (2006) *J Mass Spectrom* 41:1041–1048
- Pitarch E, Hernandez F, ten Hove J, Meiring H, Niesing W, Dijkman E, Stolker L, Hogendoorn E (2004) *J Chromatogr A* 1031:1–9
- Chiaia AC, Banta-Green C, Field J (2008) *Environ Sci Technol* 42:8841–8848
- Thompson TS, Noot DK, Forrest F, van der Heever JP, Kendall J, Keenlside J (2009) *Anal Chim Acta* 633:127–135
- Berset JD, Brenneisen R, Mathieu C (2010) *Chemosphere* 81:859–866
- Bisceglia KJ, Roberts AL, Schantz MM, Lipka KA (2010) *Anal Bioanal Chem* 398:2701–2712
- Weiss S, Reemtsma T (2005) *Anal Chem* 77:7415–7420
- Quintana JB, Reemtsma T (2007) *J Chromatogr A* 1145:110–117
- Busetti F, Linge KL, Blythe JW, Heitz A (2008) *J Chromatogr A* 1213:200–208
- Busetti F, Linge KL, Rodriguez C, Heitz A (2010) *J Environ Sci Health A* 45:542–548
- Patterson BM, Shackleton M, Furness AJ, Pearce J, Descourvieres C, Linge KL, Busetti F, Spadek T (2010) *Water Res* 44:1471–1481
- Curtin Water Quality Research Centre Perth Australia (2010) <http://cwqrc.curtin.edu.au/> Accessed 21 July 2011
- Spekniijder P, van Ravestijn J, de Voogt P (2010) *J Chromatogr A* 1217:5184–5189
- Backe W, Ort C, Brewer A, Field J (2011) *Anal Chem* 83:2622–2630
- Poole CF, Gunatilleka AD, Sethuraman R (2000) *J Chromatogr A* 885:17–39
- Gelencser A, Kiss G, Krivacsy Z, Vargapuchony Z, Hlavay J (1995) *J Chromatogr A* 693:217–225
- Gelencser A, Kiss G, Krivacsy Z, Vargapuchony Z, Hlavay J (1995) *J Chromatogr A* 693:227–233

56. Thurman E, Mills M (1998) Solid phase extraction principles and practice. Wiley, New York, p 344
57. Snyder L, Kirkland J, Dolan J (2010) Introduction to modern liquid chromatography. Wiley, Hoboken, NJ, p 912
58. Majors RE, Carr PW (2008) LC GC North America 26:118
59. Jessome LL, Volmer DA (2006) LC GC North America 24:498
60. Chassaing C, Luckwell J, Macrae P, Saunders K, Wright P, Venn R (2001) Chromatographia 53:122–130
61. Powley CR, George SW, Ryan TW, Buck RC (2005) Anal Chem 77:6353–6358
62. Yamashita N, Kannan K, Taniyasu S, Horii Y, Okazawa T, Petrick G, Gamo T (2004) Environ Sci Technol 38:5522–5528
63. Yamashita N, Kannan K, Taniyasu S, Horii Y, Petrick G, Gamo T (2005) Mar Pollut Bull 51:658–668
64. Williams S (2004) J Chromatogr A 1052:1–11
65. Bakalyar SR, Phipps C, Spruce B, Olsen K (1997) J Chromatogr A 762:167–185
66. Kozłowski ES, Dalterlo RA (2007) J Sep Sci 30:2286–2292
67. Layne J, Farcas T, Rustamov I, Ahmed F (2001) J Chromatogr A 913:233–242
68. Mills MJ, Maltas J, Lough WJ (1997) J Chromatogr A 759:1–11
69. Leon-Gonzalez ME, Rosales-Conrado N, Perez-Arribas LV, Polo-Diez LM (2010) J Chromatogr A 1217:7507–7513
70. Snyder L, Dolan J (2007) High performance gradient elution: the practical application of the linear solvent strength model. Wiley, Hoboken, NJ